

Covert cash tracking and recovery

THE CASH TRACKER




Track stolen cash for
a rapid recovery

The Cash Tracker is a powerful tracking device that blends with other currencies. It automatically detects crime and silently starts updating its location to Cennox's advanced tracking system!

Once the tracker is activated, our own 24/7 security team and local law enforcement are instantly informed. Our advanced tracking system reports the location of the cash every step of the way while law enforcement pursues and apprehends the robbers.

How does the Cash Tracker work?

The Cash Tracker automatically activates when removed from its position and alerts police and dispatch officers at the same time. Text messages and emails are also sent as notification of the alert. With the device's high sensitivity GPS system, the exact position can be tracked online. In most cases, the stolen cash is found quickly, and the criminals are arrested at the same time. Tracking information is then stored in a database for use in the follow-up investigations.



The Cash Tracker

KEY FEATURES:

- + Protects cash where it is stored
- + Thin and flexible
- + Triggers automatically with continuous motion and silently reports to our tracking website
- + Location updates from GPS, Cellular or WiFi* sent to secure website every 6 seconds to our website
- + Simple inductive charging
- + Reliable performance ensured via daily battery check and semi-monthly health check with a cellular connection
- + Text and email notifications of activations and device status
- + Stores location data if cellular signal is lost to preserve tracking data
- + RF to pinpoint final device location
- + DIY installation and charging